

## Supported systems by ATS900

<b>BRAND</b>	<b>GROUP</b>	<b>SYSTEMS</b>
<b>ALFA ROMEO</b>	<b>Airbag</b>	Airbag AB Allied 1.0
		Airbag AB Autoliv 1.0
		Airbag AB Breed 1.0
		Airbag AB Siemens 1.0
		Airbag AB TRW 1.0
		Airbag AB TRW 2.0
	<b>Engine control</b>	Motorola E16
		Motronic ME 7.9.10
		Motronic ME 7.9.10 V2
		Motronic ME 7.9.9
		Motronic MED 7.6.2
	Simtec 75.3	
<b>BMW</b>	<b>Airbag</b>	Airbag AB 2.0
		Airbag AB 8.1
		Airbag AB 8.1 R
		Airbag AB 8.1 RD
		Airbag AB 8.2 RD
		Airbag AB BAE1
		Airbag AB ZAE1
	<b>Dashboard</b>	Instruments cluster 1.2
	<b>Heating/Air conditioner</b>	Air conditioner 1.0
		Automatic A/C 1.2
		Automatic A/C 1.2.1
<b>Information for the driver</b>	Info display 1.2	
<b>Special systems</b>	Interval reset 1.2	
<b>CHEVROLET</b>	<b>Engine control</b>	GMPT-E16
		Motronic ME 7.9.6
		Motronic ME 7.9.9
		Motronic ME 9.6-1
		Multec H (LA)
		Simtec 71.6
		Simtec 75
	Trionic 8	
<b>Gear box control</b>	Automatic 4-gear GMDAT 2.0	
<b>CITROEN</b>	<b>air conditioner</b>	Automatic A/C 3.1
	<b>Airbag</b>	Airbag AB Breed 1.0
		Airbag AB Siemens 1.0
	<b>Comfort</b>	Door control unit driver 3.1
		Door control unit passenger 3.1
		Steering column manual transm. 3.2
	<b>Dashboard</b>	Combined instruments 3.1
<b>Engine control</b>	Diesel EDC Lucas DCN2	
	Sirius 81	
<b>DACIA</b>	<b>Engine control</b>	EDC Delphi DCMK

<b>FIAT</b>	<b>Airbag</b>	Airbag AB Allied 1.0
		Airbag AB Autoliv 1.0
		Airbag AB Breed 1.0
		Airbag AB Siemens 1.0
		Airbag AB TRW 1.0
		Airbag AB TRW 2.0
	<b>Comfort</b>	Door control unit driver 3.1
		Door control unit passenger 3.1
		Steering column manual transm. 3.2
	<b>Engine control</b>	IAW 4DF
		IAW 4EF
		IAW 4SGF
		IAW 5AF
		IAW 5SF V2
		Motorola E16
		Motronic ME 7.6.3
		Motronic ME 7.6.3 V2
		Motronic ME 7.9.10
		Motronic ME 7.9.10 V2
Motronic ME 7.9.9		
Motronic MED 7.6.2		
Simtec 75.3		

<b>FORD</b>	<b>Anti-block system</b>	ABS 8.0 ver. 2
		ABS 9.14.1
		ESP 8.0 Var.2
	<b>Engine control</b>	EEC5 DOHC SFI
		EEC5 Duratec-HE SFI
		EEC5 Duratec-ST SFI
		EEC5 Duratec-VE SFI
		HS CAN USA

<b>HYUNDAI</b>	<b>Engine control</b>	Motronic M 7.9.0
		Motronic M 7.9.01
		Motronic M 7.9.02
		Motronic MG 7.9.0
		Motronic MG 7.9.01
		Motronic MG 7.9.02
		MPI 4.1
		Sigma 1.0
		<b>Gear box control</b>

<b>IVECO</b>	<b>Special systems</b>	Exhaust gas finishing treatment DNO
--------------	------------------------	-------------------------------------

<b>KIA</b>	<b>Engine control</b>	Motronic M 7.9.0
		Motronic M 7.9.01
		Motronic MG 7.9.0
		Motronic MG 7.9.01
		Sigma 1.0

	<b>Gear box control</b>	4-sp.autom.transm.HIVEC5.0
--	-------------------------	----------------------------

<b>LANCIA</b>	<b>Airbag</b>	Airbag AB Allied 1.0
		Airbag AB Autoliv 1.0
		Airbag AB Breed 1.0
		Airbag AB Siemens 1.0
		Airbag AB TRW 1.0
		Airbag AB TRW 2.0
	<b>Comfort</b>	Door control unit driver 3.1
		Door control unit passenger 3.1
		Steering column manual transm. 3.2
	<b>Engine control</b>	IAW 4EF
		IAW 5AF
		IAW 5SF V2
		Motorola E16
		Motronic ME 7.9.10
		Motronic ME 7.9.10 V2
Motronic ME 7.9.9		
Motronic MED 7.6.2		
Simtec 75.3		

<b>MAZDA</b>	<b>Anti-block system</b>	ABS 9.6.1
	<b>Engine control</b>	EGI CAN 1.0
	<b>Underbody/Steering</b>	Steering support 9.6.1

<b>MERCEDES BENZ</b>	<b>Airbag</b>	Airbag AB 9.6 ARCADE
		Airbag AB 9.6 ARCADE HL
	<b>Comfort</b>	EZS 2.0
		EZS 2.1
		EZS 9.12.4
		Roof control panel 9.12.4
		Roof operating unit 2.0
		Roof operating unit 2.1
		Roof operating unit 9.12.1
		Trailer detection 2.0
	<b>Electr. gear selector lev. module</b>	EWM C/CLK
		EWM CAN1
		EWM Direct Select ISM
		Transmission selector lever module E
	<b>Electrical energy management</b>	Battery management 2.0
		EKP FSCM 1.0
		EKP FSCM 2.0
		EKP FSCM 3.0
	<b>Gear box control</b>	ATC01.02
		Autotronic CVT 1.0
	<b>Heating/Air conditioner</b>	Auto air conditioning system 2.0
		Automatic A/C 2.1
		Automatic air-conditioner 9.12.1
		Convenience autom. A/C 2.0

	<b>Lights control</b>	ALWR 906
		ALWR CAN
	<b>Service-Intervall-Display</b>	Dynamic Service Info 2.0

<b>MITSUBISHI</b>	<b>Airbag</b>	Airbag AB 3.0
	<b>Anti-block system</b>	ABS 8.0
		ABS 8.0 ver. 2
		ABS 8.0 ver.1
		ABS 9.6.2
	<b>Dashboard</b>	Instrument cluster 9.2.1
		Instrument cluster 9.6.1
<b>Engine control</b>	Motronic ME 7.7.1	
<b>Gear box control</b>	5-sp.aut.transm.F5A5A-45CZ	
<b>Heating/Air conditioner</b>	Automatic A/C 9.2.1	

<b>NISSAN</b>	<b>Break assisting system (BAS)</b>	DS seat memory 9.12.2
	<b>Special systems</b>	Exhaust gas finishing treatment DNOX
	<b>Underbody/Steering</b>	Steering support 9.6.1

<b>OPEL</b>	<b>Airbag</b>	Airbag SDM 1.0
		Airbag SDM 1.1
		Airbag SDM 44
	<b>Engine control</b>	Diesel CR/EDC Multi 6JO
		Diesel EDC 16CP33
		GMPT-E16
		Motronic ME 9.6-1
		Simtec 71.6
		Simtec 75
		Trionic 8

<b>PEUGEOT</b>	<b>air conditioner</b>	Automatic A/C 3.1
	<b>Airbag</b>	Airbag AB Breed 1.0
		Airbag AB Siemens 1.0
	<b>Comfort</b>	Door control unit driver 3.1
		Door control unit passenger 3.1
	<b>Engine control</b>	Diesel EDC Lucas DCN2
Sirius 81		

<b>RENAULT</b>	<b>Engine control</b>	Diesel EDC 16
		Diesel EDC 16CP33
		Diesel EDC 16CP33.2
		Diesel EDC 16CP33.3
		EDC Delphi CR 2.0
		EDC Delphi DCMK
S3000		

<b>SUZUKI</b>	<b>Engine control</b>	Diesel EDC 16 C3
---------------	-----------------------	------------------

<b>VOLVO</b>	<b>Engine control</b>	MEDEN V8 (Denso)
	<b>Special systems</b>	Exh. gas finishing treatment DNOX 1